Prestigio

THE ART OF HI-TECH

MultiPad 8.0 HD

PMT5587_Wi

Tablet PC

User Manual

www.prestigio.com

Common information

Dear Customer,
Thank you for choosing Prestigio MultiPad 8.0 HD (PMT5587_Wi) Tablet PC. Before starting to use the tablet, please read this manual carefully to discover all its features. Please save this manual and refer to it in the future if you have questions concerning your device.
This manual contains safety information, technical specifications of Prestigio MultiPad 8.0 HD (PMT5587_Wi) Tablet PC, preinstalled software basic features, setup and other useful information, which will help you to improve your use of the device, Android operating system and applications.
For information about meaning of the terms used in this manual, please refer to the "Glossary" section at the end of this manual, as well as to other open information sources or Prestigio customer support line.

Disclaimer

As the Prestigio products are constantly updated and improved, your device's software may have a slightly different appearance or modified functionality than presented in this User Manual. We make every effort to ensure that the information and procedures in this user manual are accurate and complete. No liability can and will be accepted for any errors or omissions. Prestigio reserves the right to make any changes without further notice to any products herein.

Important Safety Instructions

Your Prestigio MultiPad 8.0 HD (PMT5587_Wi) Tablet PC is manufactured and designed for mobile usage. Please read the following instructions carefully. It helps you to use your device without safety issues and keep your Tablet PC in good working condition:

1. Do not place objects on top of the MultiPad as objects may scratch the screen.
2. MultiPad should be kept away from extreme changes of temperature.
3. Protect it from direct sunlight or heat sources.
4. Protect the device from moisture and from dusty or smoky environment as it can harm the tablet.
5. Keep your MultiPad away from contact with active chemicals.
6. Do not place the MultiPad on an uneven or unstable surface. Fall of the device can cause damage to the LCD screen which is not covered with warranty.
7. Do not expose the MultiPad to strong magnetic or electrical field.
8. Protect your MultiPad from hits and extreme pressure.
9. Operation Temperature: This MultiPad should only be used in environments with ambient temperatures between 0°C (32°F) and 45°C (113°F).
10. Do not insert into MultiPad devices or items not matching to standard sockets on it.
11. Do not use MultiPad in the rain - it is NOT a waterproof device. Protect the Multipad from dust, dirt and high humidity.
12. Do not use Your MultiPad during driving.
13. Use only manufacturer approved chargers. Using non-original chargers may cause damage of the device and be harmful to your health.
14. The MultiPad and the adapter may produce some heat during normal operation or charging. Avoid placing it to the soft surfaces, other places and conditions which may prevent normal dispersion of the heat, causing device overheating. Do not leave the MultiPad on your lap or other part of the body to prevent discomfort or injury from heat exposure.
15. Disconnect the MultiPad from an electrical outlet after it is charged.
16. Do not use a pen or any sharp object to tap the screen. Clean the touch screen with a soft cloth. If needed, dampen the cloth slightly before cleaning. Never use abrasives or cleaning solutions.
17. DO NOT disassemble the MultiPad, only a Prestigio certified service technician should perform repair.
18. Always power off the MultiPad to install or remove external devices that does not support hot-plug.
29. Your MultiPad must be switched off during airplane take-off and landing.

Warranty Information

Warranty information could be found at www.prestigio.com/service. MultiPad 8.0 HD (PMT5587_Wi) Tablet PC life cycle is 2 years.

Contents

1.Product Overview
1.1 Package Contents
1.2 Device Overview
2. Getting Started
2.1 Charging the battery
2.2 Using the storage card
2.3 Hot plug of storage card
2.4 Memory space
2.5 Power on/off
2.6 Startup Wizard
3. Home Screen
3.1 Status and notifications
3.2 Shortcuts to Add widgets
3.3 Finger gestures
3.4 Coping files to and from the storage card
4. Personalizing
4.1 Change the Notification ringtone
4.2 Change your wallpaper
4.3 Personalize your Home screen with folders
4.4 Rearrange widgets and shortcuts on your Home screen
5. Web browsing
6. Manage Applications
7. Typical applications introduction
7.1 Music Player
7.2 Video Player
7.3 Gallery
7.4 File Manager
7.5 Instant Messaging tools
7.6 E-mails
7.7 Camera
8.Prestigio preinstalled applications
9. Settings
9.1 Wireless & networks
9.2 Audio Profiles
9.3 Display
9.4 Storage
9.5 Apps
9.6 Accounts& Sync
9.7 Location service
9.8 Security settings
9.9 Language & input setting
9.10 Backup &reset
9.11 Date & Time setting
9.12 Accessibility
9.13 Developer options
9.14 About tablet
10. Troubleshooting
10.1 Force shutdown
10.2 Restore default settings
10.3 System updating
11. Glossary
Appendix. eReader Prestigio Manual

1. Product Overview

1

1.1 Package Content:

MultiPad 8.0 HD (PMT5587_Wi) – 1x
Carrying Case - 1x
AC Adapter – 1x
USB Cable – 1x
OTG Cable – 1x
Quick Start Guide – 1x
Legal and Safety Notices – 1x
Warranty Card – 1x

1.2 Device Overview

Control Buttons and Connectivity:



1	**Power Button**	Turn on/off the device; Suspend/Activate the device. Long press about 6s to turn off the device directly
2	**Vol +\ Vol - Button**	Adjust the volume level
3	**Microphone**	Record voice or chat on line
4	**Front Camera**	Take photos or video chat on line

5	**Earphone Jack**	Earphones connection
6	**Micro SD Card Slot**	Insert Micro SD card.
7	**USB Slot**	Transfer data when connecting to PC; Connect to USB flash drive, mouse and other device via OTG cable
8	**DC Slot**	Charging when connecting to power adaptor

Technical Specifications:

Processor	
CPU	Dual Core ARM Cortex A9 AML8726-MXS
CPU Internal Clock Rate	1.50 GHz
Display	
Display Size	8.0 inches
Display Resolution	1024 x 768 pixels
Display Technology	TFT LCD
Display Features	Capacitive multi touch screen
Screen rotation	G-Sensor
Graphic Card	
GPU	Dual Core Mali 400 MP
GPU Speed	350Mhz
Memory	
Internal Memory Size	8 GB
Installed RAM Storage Capacity	1 GB DDR3
Flash Card	Supported 32GB Micro SDHC/SDXC
Phone Features	
Phone Protocols	No
Phone Technology	No
Phone Bands	No
Interfaces	
Interface	Wi-Fi, Micro SDHC, Micro SD, Micro USB 2.0
Interface Wi-Fi	IEEE 802.11b/g/n
Interface HDMI	No
Interface USB	1 x Micro USB
Interface Audio	1 x 3.5 mm mini jack
Multimedia	
Digital Camera	Front : 0.3 Mpixel
Supported eBook Formats	EPUB, PDF, TXT, FB2
Supported Audio Formats	MP1, MP2, MP3, WAV, WMA, APE, OGA, OGG, AAC, FLAC, M4A
Supported Picture Formats	BMP, GIF, JPG, PNG
Supported Video Formats	DAT, MPG, TS, VOB, AVI, MKV, MOV, MP4, 3GP, RM, RMVB, FLV, WebM, WMV, ASF
Video Features	FullHD Playback
Sound Features	Stereo Audio Playback
Software	
Operating System	Android 4.2 (upgradable)
Battery	
Battery Technology	Lithium Ion Polymer
Battery Current Capacity	5000 mAh
Battery Video playback Time	Up to 3.5hr
Battery Audio playback Time	Up to 36hr
Battery Standby Time	Up to 120hr
Miscellaneous	
Built-in Devices	Card Reader, Microphone, Stereo Speakers
Included Accessories	Power Adapter, USB Cable, Quick Start guide, OTG-cable, Stylish leather pouch, Warranty Card
System Requirements	Microsoft Windows 2000, Microsoft Windows 7, Microsoft Windows Vista, Microsoft Windows XP, Linux 2.4.0 or Later, Apple Mac OS X 10.4 or Later
Applications Installed	Music, Camera, Gallery, Clock, Browser, Calculator, Calendar, E-Mail, Google Play, Explorer, Gmail, Google Maps, Office Suite, Blue, Facebook, Twitter, Youtube, eBook, Video, FreeNote, Stock Alert, Barcode Scanner, Currency Converter, Angry Birds, Chess Free, 250+ Solitairs, Skype, eReader Prestigio, SugarSync, OTA updates Maps, FreeNote, Stock Alert, Currency Converter, Angry Birds
Dimensions & Weight Device	

Width (mm)	216.3
Height (mm)	138.4
Depth (mm)	10.1
Nominal Weight (kg)	0.46
Warranty	
Warranty Term (month)	24 month
Temperature and Humidity	
Storage Temperature	0°C (32°F) ~ +60°C (140°F)
Operation Temperature	0°C (32°F) ~+45°C (113°F)
Storage Relative Humidity	0% ~ 90%, Non-Condensed
Operating Relative Humidity	0% ~ 90%, Non-Condensed

2. Getting Started

2

2.1 Charging the battery

Prestigio MultiPad comes with a built-in lithium-Ion rechargeable battery and is designed to use only manufacture-specified original batteries and accessories. You can see battery status on status bar of MultiPad in the lower right corner of the home screen. Android OS has battery charge detection system and notify user if battery charge is low and device need to be connected to AC adapter. If you will see such message, or your device couldn't power on, connect original AC power adapter to charge your device.

☐ the power adapter connector o

to the wall socket for charging.

Normally it takes approximately 5.5 hours to fully charge the device. Operating the device while charging with the AC adapter may extend the time of full charging.

Please, fully charge your new device after unpacking.

[Note]: it is normal if the device is warm or hot during charging, you can use it as usual, just follow the respective security precautions.

Please be informed, that Li-Ion battery is considered to be a consumable part of your MultiPad, it's rated capacity might fall up to 50% during first two years from the date of purchase; such reduction of capacity is not a defect and is not covered with warranty.



2.2 Using the storage card

Your new Prestigio MultiPad 8.0 HD (PMT5587_Wi) Tablet PC is equipped with Micro SD card slot to extend available device memory. It is compatible with Micro SD/ Micro SDHC card formats of size up to 32Gb.Proper functioning of larger capacity cards is not guaranteed.

Insert a Micro SD/SDHC cards:

- The device supports micro SD/SDHC cards.
- To insert a Micro SD card, place the card connector towards the rearside of the device and the printing side of the card towards the front side of the device.
- To remove the micro SD card, gently press the edge of the card to release the safety lock and pull the card out of the slot.

- To access the files on the memory card, select**File Browser** icon and tap on **SD Card**.

[Note]: When you are reading the file from micro SD card, please don't remove it,or the device could fail to operate correctly.

Don't insert or remove the SD card while the device is on. Please insert or remove the SD card while the device is off.



Browse files in the storage card

To browse the files you should do one of the following:

- Select "Explorer" icon to view files in the storage card;
- You can also install and run any other third party file browser applications.

Remove the storage card

To avoid data loss or damage, please stop using files/programs in the storage card, and then tap Settings>Storage>Unmounts Storage to remove it safely.

To remove the storage card, gently press the edge of the card to release the safety lock and pull the card out of the slot.

[Note]:

1. Make sure the location and direction of the storage card is correct when inserting.
2. To avoid possible issues or incompatibility of the storage card with your MultiPad, major brands of storage card are recommended. Never use damaged or cracked storage cards as this might damage the MultiPad or cause loss of your data.

2.3 Hot plug of storage card

Please do not hot plug the storage card when using or browsing its files.

For example, when you are running the Music/Video Player/ Gallery, the storage card could be damaged and files on it might be come corrupt if you take out the storage card without proper preparation. As for details of inserting/removing storage card, see ***2.2 Use the storage card***.

2.4 Memory space

The capacity of built-in flash chip is 8GB. The device contains 2 memory partitions: Internal storage &NAND Flash storage. The space is partitioned to store apps, setting and user data. A part of storage will be reserved for system resources and wouldn't be available for user. The exact size of available memory may vary depending on Firmware version.

MultiPad supports extended storage – micro SD cards of 32GB maximum capacity.

2.5 Power on/off

1. **Power on:** To turn on the device, press and hold the **Power Button** until you see the start-up screen then release. It will automatically enter the **Home** screen.
2. **Power off:** Press and hold the **Power Button,** and then tap on **OK** to power off the device. Press and hold the Power Button for about 6s, it will power off directly.
3. **Screen Lock：** short-press down the Power Button once to shut down the screen to save battery life. Short-press down the Power Button again to activate the lock screen. After unlocking, the device will resume the screen before locking.

2.6 Startup Wizard

Prestigio Startup Wizard will guide you through the initial setup of your MultiPad. It appears at first start and consists of several steps. Following information will help you to avoid issues during that stage.

Welcome! Screen allows you to choose the desired language of the operational system of Prestigio MultiPad. Tap “Change language” button to access a list of available languages. You can select the language you need in this list, than you’ll return back to the Welcome screen. Tap next, read and accept End User License agreement to continue.

Please, note that in case you refuse to accept EULA (Dismiss button) you won’t be able to proceed with device activation.



Keyboard Input Language screen provides users with option to select the necessary layouts of Android Keyboard.


PrestigioWizard
Keyboard Input Language
Your keyboard layout is set by default to ENGLISH.
If you want to set other layouts for the keyboard, please, press CHANGE and mark all required languages including ENGLISH.
CHANGE
Back is not allowed here.
Please proceed with the Startup Wizard.
Previous
Next
14:00

You may select several layouts (e.g. English (US) and German) by checking respective checkboxes.

Tap and to continue when ready.

Date and Time screen has to be used for exact Time Zone setup. By default the MultiPad tries to retrieve use time information from Internet time servers.


PrestigioWizard
Date and Time
The time zone currently set is:
British Summer Time (GMT+1:00)
Your device is configured to set its clock automatically as soon as it will be connected to the internet.
You can also choose to set it manually by pressing on this button:
Advanced settings
Previous
Next
14:00

In case you do not have an Internet access right now you may Advance Options button, turn Automatic date & time OFF and configure manually.



Tap **Next** button to continue to **Wi-Fi connection screen**.



To connect to a Wi-Fi network, you should tap button **Configure Wi-Fi**, choose your wireless network name in a list and enter its password in pop-up menu:



You may check the **Show Password** option in order to make it visible, but please consider the possible security risks.

After successful connection, the Wi-Fi connected icon will appear on the status bar.

Tap and Next to continue.

Third party applications screen allows the customer to install the pack of programs which enhance Multipads functionality. Depending on the exact version of Firmware, the following options are available.

A default Android **Third party applications** tool. In case of this option (see screenshot below) a user can either decide to install the pre-loaded content by tapping Install button, or skip the third party application stage. In case of **Don't Install** choice the wizard will automatically continue to final screen. Otherwise the installation sequence will be initiated.


Installer Prestigio
Third party applications
SugarSync
SugarSync puts ALL of your data from all of your computers right at your fingertips... anytime, anywhere from your Android device. With SugarSync, you get free cloud backup that you can use to sync files, share folders, and access your data directly from your Android device. If you like Dropbox, iCloud, or Carbonite, you'll love SugarSync.
To install
Twitter
Official Twitter app for Android. Wherever you are, Twitter brings you closer.
To install
YouTube
Keep up with your favorite YouTube channels and access the world's videos anywhere with the official YouTube app for Android.
Regional Apps
Apps that are proposed by Prestigio and their partners for your region.
Check Online Now
Don't install
Install
Previous
12:54

Alternatively, an **Installer Prestigio** could be launched instead of default third party installation wizard.


Installer Prestigio
Third party applications
Common Apps
Apps that are universal for any country. To be installed from your device.
No preloaded apps in your device
Regional Apps
Check Online Now
Third party applications
The Android Applications which are going to be installed have been developed by Android's users or other companies, not by Prestigio and are provided at no charge. Unless indicated otherwise, Prestigio makes no promises nor representations and takes no responsibilities about their performance, quality, content or intellectual property rights.
OK
Previous
Saving screenshot...
Screenshot is being saved
14:03

This utility has the extended functionality comparing the default Third party application utility. It provides user with the better tools for management of pre-loaded applications and games. **Installer Prestigio** scans the MultiPad for installation files pre-loaded during production, displaying the found application in a list. In addition, it offers the customer to check online Prestigio repository for applications and games for this particular model and region. Tap **Check Online Now** button to use this option. Application name, as well as its brief description and size to download will be displayed in the list.

You may check the desired ones and tap **Download and Install** button. After you accept the Legal disclaimer the installation starts. After it finishes installation successfully Wizard will automatically continue to the **Thank you!** Screen:



Now you can tap **OK** button and start using your MultiPad. Hope you will enjoy this experience. Thank you!

3. Home Screen

The Home screen is your starting point to access all the features on you device. It displays application icons, widgets, shortcuts, and other features. You can customize the Home screen with different wallpaper & widgets and display items you want. See the ***Personalizing*** section in this manual.
When you start, the Home screen appears.

Sleep mode

Sleep mode suspends your device to a low power state while the display is off in order to save battery power. You will still be able to receive messages while the device is in Sleep mode.
[Note]: By default the device enters sleep mode automatically in case it's not operated for 2 minutes. You may change this time or even disable automatic sleep mode activation in menu **Settings-Device-Display-Sleep**.

Wake up from sleep mode

To wake up your device manually, press the Power Button. You will see a Lock Screen than.

Unlocking the screen

Touch the lock icon , hold it and slide towards.

Please note, that depending on the direction you move the unlock icon, you may just unlock the MultiPad and enter Home screen, start the Camera application.



Other unlock ways, like PIN code, Face Unlock, Pattern etc. could be set up by user in menu **Settings-Personal-Security-Screen Security – Screen Lock.**

Browse Home Screen

You can go to the extended Home screen by sliding your finger horizontally across the screen to go to the left or right side of the Home screen. Tap the icon to view all applications on your device.

3.1 Status and notifications

Status and Notification Icons may appear.

The status bar contains different information like time and date, battery status, wireless networks status, active notifications from Android OS or installed applications and so on. When an application is running, corresponding notification icon will appear in the notification area. Icons you may often see are listed as follows:

Status icons and its meanings	
	Tap to go to the Home screen
	Back
	Recently applications view
	Menu icon
	Android debug bridge enabled
	Connected to a Wi-Fi network and display the signal strength
	Accounts & synchronization
	Display (brightness)
	Battery status
Notification icons its meanings	
	New Gmail (Google Mail) message
	New Email message
	Music player is ongoing
	Video Player
	SD card is mounted
	USB Connected
	Settings

Open notification panel

If a new notification icon displays in the status bar, touch and hold the status bar, then slide your finger upwards to open the Notifications panel as follows:



If you have several notifications, you can scroll down the screen to view more notifications.
In the notification panel there are shortcuts for quick access to **Settings** and **Wi-Fi** tabs.

Close the Notifications panel

Simply touch the Back button on the device panel.

3.2 Shortcuts to Add widgets

Widgets put at-a-glance important information and media content up front on your Home screen. Some widgets are already added to your Home screen for your convenience. You can add more from the available selection of widgets, or download more widgets.

Adding a widget to your Home screen

To add widgets to Home screen, you can:

-Tap on the home screen to enter into all apps interface as follows:

- Tap **WIDGETS**

- Select one item. Touch and hold your finger on widget. Choose desired place for widget on the home screen.

[Note]: When choosing place for widget you can switch home screen tabs by sliding finger with holding widget to the left or right side of the home screen.

Examples of Widgets are as follows:



Removing widget from your Home screen

To remove a widget, touch and hold the widget until the icon “X Remove” or “X” appears at the top of the screen, drag the widget onto it, so the widget you want to remove has become red and release your finger.

3.3 Finger gestures

Tap: When you want to type using the keyboard, select items on screen such as application and settings icons, or touch on screen buttons, simply tap them with your finger.

Touch and hold: To open the available option for an item (e.g. contact or link in a web page), simply touch and hold the item.

Swipe or slide: To swipe or slide means to drag your finger vertically or horizontally across the screen.

Drag: Touch the object before you start to drag. While dragging, do not release your finger until you have reached the target position.

Rotate: For most screens, you can automatically change the screen orientation from portrait to landscape by turning the device sideways. When entering text, you can turn the device sideways to bring up a bigger keyboard. Refer to Settings chapter for more details.

3.4 Coping files to and from the storage card

You can copy music, photos/pictures and others to MultiPad to personalize your device.

1. Use the USB cable that came with your device to connect it to an USB port on your computer.
2. When the icon appears in the notification area, you will see in the right down corner “Connected as a media device”
3. The computer will recognize your device as a removable disk;
4. Find the removable disk and open it. Do one of the followings:

- Copy the files from the computer to the storage card’s root folder.
- Copy the files from the storage card to a folder in your computer or computer desktop.

4. After copying the files, if you would like to disconnect the device physically from computer, please unmounts the removable disk (that is, your device) as required by your computer’s operating system to safely remove your device.
5. Disconnect your device from the computer.

4. Personalizing

4.1 Change the Notification ringtone

Choose from the available selections of notification ringtones on your device. You can also download or copy notification ringtones or songs to your device's storage card and choose one to use as your notification ringtone. To find out how you can copy files to your storage card, see “Copying files to and from the storage card”.

1. In the Home screen, tap Settings >Device > Sound> System>Default notification.
2. Tap the notification ringtone you want to use. The notification ringtone briefly plays when selected.
3. Tap **OK**.

4.2 Change your wallpaper

Personalizing your Home screen wallpaper with your favorite photo is a quick and easy way to change the feel of your device and give it a fresh look. Browse the collection of wallpapers included in your device or choose from photos that you have taken with the camera.

To change your Home screen or lock screen wallpaper:

1. On the Home screen touch and hold your finger at the free area. **Choose wallpaper from** menu will appears.

[Note]: You can also tap Settings>Display>Wallpaper to reach **Choose wallpaper from** menu.

2. Choose source and wallpaper you would like to use.

You can do one of the following:

- Tap **Gallery** to select a photo/picture that you have taken using the camera or copied to your storage card. Tap **Crop** to crop the photo/picture and set the cropped picture as wallpaper.
- Tap **Wallpaper** gallery to choose from preset wallpapers and then tap **Set wallpaper**.
- Tap **Live Wallpaper** gallery to choose from preset live wallpapers and then tap **Set wallpaper**.

4.3 Personalize your Home screen with folders

Use folders to group related applications and other shortcuts to keep your Home screen tidy and organized.

4.3.1. Adding folders on your Home screen

Touch and hold the application shortcut and drag it onto another shortcut to create a folder for the applications you want to file together, and then release your finger to finish creating a folder. You can drag any other application shortcut into the new folder.

To rename a folder:

1. Tap the folder to open it.
2. Tap **Unnamed Folder** to prompt the keyboard.
3. Enter a new folder name and then tap Enter key.

4.3.2. Removing folders from Your Home screen

Tap the folder you want to remove to open it. One by one touch and hold application shortcut inside folder and drag it out of the folder. When only one application shortcut will stay inside the folder, folder will be automatically deleted.

[Note]: During operations with folders your application shortcuts are not removed.

4.4 Rearrange widgets and shortcuts on your Home screen

Rearrange widgets and shortcuts on your Home screen to get space for adding more items to the Home screen.

4.4.1. Moving a widget or shortcut

1. Gently tap and hold the widget or shortcut you want to move.
   You'll see a blue edging around the widget or shortcut. Don't release your finger.
2. Drag the widget or shortcut to a new location on the screen.
   Pause at the left or right edge of the screen to drag the widget or shortcut onto another Home screen panel.
3. When the widget or shortcut is where you want it, release your finger.
   If you've released your finger but a message shows that there's no space to place the widget or shortcut, drag it right or left again to another Home screen panel.

4.4.2. Removing shortcuts

To remove a shortcut, touch and hold the shortcut until the icon "X Remove" or "X" appears at the top of the screen, drag the shortcut onto it so the shortcut you want to remove has become red and release your finger.

5. Web browsing

User can connect to the network via the browser.

Tap the browser icon on the Home screen to open it as follows:


Prestigio was presented...
http://www.prestigio.com/news/press/Prestigio_is_named_Peripherals_Vendor_of_the_Year
Select Prestigio resources
Select country
My Prestigio
Prestigio
Where to buy
Support
Search
MultiPads
MultiPhones
MultiReaders
DVRs
Navigators
PCs
Accessories
Home › News › Prestigio® is named "Peripherals Vendor of the Year"
Company news
Prestigio® is named "Peripherals Vendor of the Year"
04/03/2013
On March 31st Prestigio® was presented with the "Peripherals Vendor of the Year" award during the annual Channel ME Awards 2013 event held at Fairmont the Palm in Dubai.
Prestigio and iGO Primo with Navteq maps– Always the right way
You have never be so fast and intuitive on the road, but thanks to Prestigio and iGO Primo, you can be.
Enjoy your trip with Prestigio and NAVITEL® devices
Travelling has never been so much
15:19

Use keyboard to type URL (web-site address) or search phrase at the address bar.

Please note, that the browser supports tabs, you may open multiple tabs in a single browser window, switch them by a single touch or close the tabs at your choice.

Touch to open a new tab.

Touch to close the tab.

This icon allows you to reload the active page.

To exit browser application just tap Back button.

Check and manage bookmarks/history/saved pages

Add the current sheet to bookmarks

Call out search bar for search or type URL

You can use two fingers to slide for browsing or to zoom in/out

6. Manage Applications

You can personalize MultiPad and enrich your experience with it by installing a wide variety of free and paid apps ranging from productivity apps, entertainment, to games. When you find a program you want, you can easily download and install it on your MultiPad with just a few steps as follows:

How to install Android programs

1. Tap at the Home screen to enter into all apps interface. Run **Play Store** application.
2. During first launch Play Store will request you to login or register a new account. Enter your E-mail and password if you have a Google account already. Otherwise tap Create account and follow the instructions.
3. After signing in you will be able to search, download and install applications from Play Store. Some applications are free, while other might charge you through credit card.
4. Use Play Store interface to install program to your device.





How to uninstall Android programs

To uninstall the program:

1. Go to Settings>Apps>Downloadedmenu.
2. Tap on program you want to uninstall.
3. Tap **Uninstall** and **OK** in popup menu.

[Note]: You can also use an alternative way of uninstallation: enter the list of applications, tap the application you'd like to uninstall, hold it and drag to the "Uninstall" icon on top of the display.

7. Typical applications

7

7.1 Music Player

Enjoy listening to songs and music on your MultiPad using the Music application. You need to copy music files to your storage card first to use the Music application to play music. To find out how to copy files, see ***"Copying files to and from the storage card"***. Supported audio formats see in MultiPad technical specifications above.

Tap the icon **Play Music** on the Home screen to enter the following screen:





Your music is organized into different categories such as Artists, Songs and Albums. Tap one of the category tabs to view a category. Select a song in the playlist and tap on it to start playing as follows:

	Tap to go to the previous song.
	Tap to play, pause, or resume playing the song
	Tap to go to the next song
	Tap to switch the following repeat modes: repeat all songs, repeat current song, do not repeat
	Tap to shuffle the current playlist
	.Tap to repeat current song
	Tap to have a look the name of artists and songs

When you are playing music and the screen turns off, you can control the music playback volume with hardware buttons Vol+\Vol-.

7.2 Video Player

You can use the video player on your tablet to watch the videos.

Tap the icon on the Home screen and then tap the Video player icon to go to the following interface. Double tap on a video file to start playing it.



Tap the on-screen controls to control the video playback. Press the volume button to adjust the volume.

You can share your photos with another device via email.

Share videos by Email

Tap the video that you want to share. Tap to open drop-down list, and then tap Email.

Choose an Email account. Compose your message. Tap to send the mail.

If you have multiple email accounts, the default email account will be used.

To quit the video playing screen, touch the Back icon in the status bar directly.

7.3 Gallery

You use Gallery to view pictures and play videos that you've taken with Camera, downloaded, or copied

onto your SD card. You can perform basic editing tasks on pictures and set them as your wallpaper or contact picture. You can also share your pictures and videos with friends.

On the Home screen tap the launcher icon and Gallery icon after. Photos and videos are classified automatically for easy view. The gallery application will run and the interface is as follows:



Browse & edit pictures/photos

Tap an album to open it and view its contents;

This icon could be found on upper right corner of the screen; it allows you to browse all photos/pictures in slideshow mode.
Select a picture to view it in full screen mode; drag left or right to view the next or previous picture in the album; move your fingers inward/outward to zoom out/zoom in the selected photo/picture.
- This button allows you to share it with friends via email, Twitter, Facebook etc.
Use delete icon to delete the selected files.
Tap to pop-up the following control menu:



Slideshow - starts a slide show of all pictures in the album;

Edit - To edit the selected picture. When the picture is zoomed in, drag the picture to view parts that are not in view. When the picture is zoomed to fit the window, drag left or right to view the next or previous picture in the album.

Rotate left Or Rotate right to rotate the picture/photo 90° anticlockwise or clockwise;

If you tap Crop icon the following cropping rectangle will appear on top of the picture/photo:

Drag from the inside of the cropping tool to move it; drag an edge of the cropping tool to resize it to any proportion; drag a corner of the cropping tool to resize it with a fixed proportions.

Tap CROP to save a copy of the picture as you cropped it. The original (not cropped) version remains on your SD card.

Set picture as To set the current picture/photo as wallpaper;

Details To see more details about the current picture/photo.

7.4 File Manager

Introduction to File Manager

Tap the icon to view all applications on your device. Tap the File Browser (Explorer) icon to open it as follows:



File Management

In the above screen, you can navigate your storage and manage your files in the local disk and your storage card: copy/paste, delete, move and rename file and folder and send them via mail or Skype.

7.5 Instant Messaging tools

You can download from Google Play and install chat tools on your device such as Skype, Fring, and ICQ etc.

7.6 Emails

Tap the launcher icon on the Home screen to display all icons, tap the Email/Gmail icon to run it.

With help of Prestigio MultiPad you can:

1. Setup mail accounts
2. Create new mails

3. Receive and send mails
4. Download or open the attached files

7.7 Camera

The Camera app is a combination of a camera and camcorder. You may toggle between these two modes by touching respective icons and .

To take pictures and videos touch the Camera icon on a Home or All Apps screen.



Watch a video

On the home screen or list menu, tap in the Gallery app's Album, go to the video that you want to watch. Tap on-screen controls to control the video playback. Press the volume button to adjust the volume.

Edit your photos

When viewing a photo, tap and use the following functions:
Slideshow: Start a slideshow with the images in the current folder.
Edit: Launch Paper Artist to edit the photo.
Rotate left: Rotate anticlockwise.
Rotate right: Rotate clockwise.
Crop: Resize the orange frame to crop and save the photo in it.
Set picture as: Set the photo as a wallpaper or a contact image.
Details: Check information of the photo.

8. Prestigio preinstalled apps

8

Your new MultiPad contains several applications preinstalled by Prestigio to make using MultiPad more comfortable right from the box.

Following applications you can find in all apps list by touching icon on the Home screen:

Application		Description
	eReader Prestigio	Prestigio branded bookstore. You can download and read Your favorite books are here. Please read a detailed eReader Prestigio User manual provided (Appendix A)
	Office Suite	Increase Your productivity with mobile office application.
	Games	And games, of course. Angry Birds – favorite game of millions! Classic Chess – game of all times.
	SugarSync	Let Your important files synchronized from everywhere! It is a client for cloud storage service.
	File Browser (Explorer)	Manage Your files with this application.

9. Settings

Control and customize your device settings on the Settings screen.

To open the Settings screen, simply tap the Settings icon on the Home screen.

You can scroll on the screen upwards/downwards to check the rest setting items.

9.1 Wireless & networks

Configure your device's wireless connections, e.g., Wi-Fi, Virtual Private Networks, or set the options for Portable hotspot.

Wi-Fi

To turn on/off Wi-Fi, simply slide your finger rightward/leftward on the control bar.



Data Usage

Data usage menu lets you to control 2G data connections, to monitor total usage by network type and application and then set limits if needed.



More…

This menu allows you to setup Virtual Private Network (VPN) or enable Wi-Fi hotspot.



9.2 Audio Profiles

Set the device and notification ring tones, volume adjust, system sounds.



Volumes

To adjust the volume for media, ringtone, notification and alarms:

1. Tap Settings > Device >General> Volumes;
2. Drag the control bar leftwards/rightwards to turn down/up the volume for media and notification;
3. Tap **OK**.

Ringtones & Notifications

To set a notification ringtone:

4. Tap Settings >Devise>Sound >System>Default notification
5. Tap a ringtone to listen it
6. Enable a ringtone as notification ringtone by tapping **OK**.

System

Tap Settings >Devise>Sound >System. Use the checkers to enable/disable Touch sounds or screen lock sound.

9.3 Display

Set the screen brightness, auto-rotate option, wallpaper, screen timeout and font size.



Brightness

Use the slider to set a brightness level you want at all times when using MultiPad. For the best battery performance, use the dimmest comfortable brightness.

Wallpaper

Tap to select source of wallpaper and set wallpaper for the device.

Sleep

Open a dialog where you can set how long to wait after you tap the screen or touch a button before the screen darkens. For the best battery performance, use the shortest convenient timeout.

Font size

Open a dialog where you can set font size.

9.4 Storage

Check the usage condition of the storage space on the internal & external storage card. You can erase all data on the SD card and unmounts the external SD card for safety removal.
Unmounts the SD card: Tap Settings > Storage >Unmount storage > OK.



9.5 Apps

Manage applications and installation of new programs.



Apps

Open a list of all the applications and other software installed on your MultiPad, along with their sizes. By default, only downloaded applications are shown, and they are sorted in alphabetical order. Touch and tap **Sort by size** to display applications in order by size. Tap an application to open its Application Info screen.

To manage and /or remove downloaded applications, tap Settings > Apps > Downloaded.

Running services

To check and control running service, tap Settings > Apps > Running.

9.6 Accounts & Sync

Log in or out from your social network accounts, Google Account, and Exchange ActiveSync account. You can also manage synchronization and other settings for your accounts.

Tap ADD ACCOUNT in the above screen to add new accounts by following onscreen instructions. Tap the icon to prompt the following screen to manage your accounts:





Check to turn on/off data synchronization, touch the menu icon and then tap **Remove account** to remove the selected account from your device.

9.7 Location service

Enable applications using data from sources such as Wi-Fi and mobile networks to orientate your location and improve Google search results via check the options.



9.8 Security settings

Set the screen lock mode and owner information, encrypt your device, manage password and administrate your device.



To personalize the screen lock mode of your device, tap **Settings>Security>Scren Security> Screen lock**
The following options are possible to choose:

- **None** – this one means no screen lock will be enabled at sleep/resume/system on step
- **Slide** – you have to slide the screen lock button to one of directions (unlock-camera-Google web-page)
- **Pattern**- lets you draw a simple pattern with your finger to unlock the phone. This is slightly more secure than Face Unlock.
- **PIN – If you choose this option it will require you to enter 4 or more numbers to unlock the Multipad**
- **Password -** This is the most secure option, as long as you create a strong password.

[Note]: There is no way to recover password/pin/pattern lock, in case you forget the correct logon info. The only way to erase this lock is to perform complete device reset or, e.g. firmware reinstallation. All user's apps and files will be lost in this case.

Owner Info

It's possible to show owner's info on lock screen. Choose this option in this menu and Type the text to display on the lock screen in the text box below.

Passwords

Check the box if you'd like to make the passwords visible while you enter them.

Device administration

You may view or deactivate device administrators in this menu, as well as enable installation of apps from unknown sources.

Unknown sources

Check to permit installation of applications that you obtain from web sites, email, or other locations other than Google Play Store.

9.9Language & input settings

Set the operating system language and region by touching the setup icon. You can also set onscreen keyboard options.



9.10 Backup & reset

You can enable or disable the automatic backup feature of the device and reset the device.



[Note]: after factory data reset, you personalizing settings and the installed third-party applications will be removed from your device. Before restoring default settings, it is suggested to backup data/applications you want and remove your storage card safely in case of data loss or damage during restoring factory default settings.

9.11 Date & Time setting

Set the date and time, time zone, and date or time format. To turn off auto time synchronization simple unmark it and you will be able to manually change time settings.



9.12 Accessibility



Speak passwords: check to enable speak password

Touch & hold delay: 3 levels of delay when touch and hold widget or icon are available – Short, Medium, Long. It regulates the duration of object hold till further actions.

9.13 Developer options

You can set the USB debugging mode, select screen stay awake while charging and so on. And you can also manage user interface and apps.



USB debugging: Check to permit debugging tools on a computer to communicate with your MultiPad via a USB connection.

Stay awake: Check to prevent the screen from dimming and locking when the MultiPad is connected to a charger or to a USB device that provides power. Don't use this setting with a static image on the MultiPad for long periods of time, or the screen may be marked with that image.

Allow mock locations: Check to permit a development tool on a computer to control where the MultiPad believes it is located, rather than using the internal methods for this purpose.

9.14 About tablet

View the device status such as the network type, battery power level, and network name. You can also check the battery use of individual applications or view the legal information and firmware version (Build number; symbols vx.x.x) of your MultiPad.



10. Troubleshooting

10

10.1 Forced shutdown

Press and hold the Power button for more than ten seconds and the device will be forced shutdown. This operation might cause data loss though, so please backup important information on a regular basis.

10.2 Restore default settings

To restore the factory default settings, you can tap Settings > Backup & reset> Factory data reset.

Warning: data of your Google account, your personalized settings, and installed applications will be removed from your device once you execute factory default settings, so please make a careful decision whether to restore default settings. Before restoring default settings, it is suggested to backup data/applications you want.

10.3 System updating

After system update/upgrade, it may occur that the installed third-party applications cannot run or there is data loss or damage to the apps. This is normal phenomena rather than a system fault. You just need to download and install the third-party applications again into the device. It is recommended to backup data of the third-party applications before system update/upgrade.

Please note, that Prestigio provides OTA (Over-the-Air) update service to its customers. You may turn on/off automatic updates and perform a manual check in the following screen accessible via Settings>About Tablet>System updates:



11. Glossary

Android 4.2 (upgradable) operating system for Tablet PCs and smartphones based on Linux kernel;

Google Play Store– online store with software for Android OS;

Google Account- pre registered user account for having access to the Google branded services and registration of MultiPad;

MultiPad– Prestigio trademark for Tablet PC devices;

Gmail – Google branded e-mail client;

Widgets– simple programs on the Tablet PC desktop for showing different information or shortcuts to connected installed software.

EReader Prestigio Manual

1. Launching the application.

Open list of applications or main desktop window to find eReader Prestigio icon Tap on it to start application. Please, wait until spinner in the right top corner disappears.



While loading application will check the default folder for the available content (mnt/sdcard/Books) and display it on the shelves.



Some of the content is already preloaded on the factory and divided by languages for your comfort use.

Tap “My books” to open a list of preset folders and choose the one that corresponds to your language. Other collections can be deleted through Edit option.



2. Main Control panel.

Settings can be called from the notification bar . Use opened options to make a quick Search, Refresh your content or Enter in Settings.



Localization. Set a custom language for your application that can be different from the Android system language.
Directories. Set any custom directory from which books will be available on the shelves.
Adobe device activation. Set Adobe Id to allow working with Adobe DRM protected books.

3. Navigation in main sections.



My Shelf is graphic presentation of the books content and its control.
My Library is the File tree and automatic grouping of the books between several assigned categories: Collections, Favorites, Recent.
Bookstore is the online shop of the books proposed by Prestigio to their customers in 22 languages with the possibility to Search and purchase any book directly from application.

4. Content control bar.



1 - Sort of the current shelves by title, author name, favorites or recently added
2 - Pagination block. Go to the next shelf in the frame of the same Collection or type a number of a shelf if you have more.
3 Search a book with its title or its author's name. Enough to type part of the name to start Searching. Found books will be shown on the shelf. To return to the collection view it's necessary to empty search bar and press done.
4 - Collections list. Application works with folders if you already have your own library on the PC you can copy to a Prestigio e-book reader or create markers on any book

5. Work with the Collections.

“My books” contains all the books from the selected directory. It’s a default collection that can’t be removed or renamed.
Press on “My books” or “Collections” to start navigation in the list of preset or preloaded collections.

List of the collections can be edited through Edit or Add new button.



Edit. Option allows you renaming collections or deleting any selected with a marker collection. Delete the collection doesn’t mean that books will be erased physically from the device.



Any book or a group of the books can be moved from one collection to another or deleted from the device and collection.

Select 

on the main shelf to start working with books.
A new control bar will be available.

Move - Allows to move a book from a collection to another chosen collection.
Delete - Remove all selected books from the application and device.
Select all - Option will mark all books not only on the opened shelf but on all other shelves of a collection. Be very careful as it also allows to delete all books from the collection.
Done -Tap when all operations with the books on the shelves are finished.

When Edit option is activated on the shelf it’s possible to mark any book on any shelf just by clicking on a cover. Then other options will help to Move or Delete chosen content.

6. Reading a book.

To read a book it's enough to press on its cover on a shelf.

Settings options can be opened via Context menu icon .



Book info. Display information about the book
Bookmarks. Return to the most interesting places in a book with a bookmarks made.
Night. By default any book is read in Day mode (white backend + black font). It can be easily switched to a night mode to keep user's eyes in safe.
Search. Allows to find a word or expression in the text of a book.
Settings. Customization option to get the reading experience in a comfortable way: Appearance, Text size, Text font, Colors and Wallpapers, Scrolling and Indicators.
More… Open navigation panel to jump easily to any book page, adjust Brightness or set Font size with one touch.

Any read book will appear on the main screen in Recent read section from the left side.

Press on the book from the shelf to continue reading from the last opened page.

7. Work with Bookstore.

Bookstore in the device is available in the form of OPDS catalog: simple form of the books list that mirrors www.ebooks.prestigioplaza.com web-shop.

Catalog can be navigated like a tree with 2 main categories: Themes & genres and Authors.



Continue navigation until you find a book or a genre that might be interesting for you.

To search for a specific author or a book use the option **Network Search.**

Refresh catalogs can be used in a case when first connection to Bookstore was made without Internet connection.



Found book will be displayed with a detailed info and price if applicable. Free books will have **Download** button instead of **Buy**…


&quote;The Busiest Man in England&quote; - Grant Allen and the Writing Trade, 1875-1900
Book Info
Title: &quote;The Busiest Man in England&quote; - Grant Allen and the Writing Trade, 1875-1900
Authors: Peter Morton
Tags: Publicism
Catalog:
Description
This book is the first critical biography of Grant Allen (1848-1899) in a century, based on all the surviving primary sources. Despite his lifelong ill health and relatively short life, Allen was a writer of extraordinary productivity and range. About half of his work reflects interests which ran from Darwinian biology to cultural travel guides. His prosperity, however, was underpinned by fiction; he wrote more than thirty novels, including The Woman Who Did, which has attracted much recent attention from feminist critics and historians. &quote;The Busiest Man in England&quote; uses Allen's career to examine the role and status of the freelance author/journalist in the late Victorian period, and analyzes what it took to succeed in this notoriously tough profession.
Buy (€89.26)
07:35

To purchase a book press **Buy**… and then **Sign in** or Register My Prestigio account. If account is active and balance is enough to make a transaction then download will be started automatically.

`

Attention: in case of unstable Internet connection or if download didn't start, please, check **My orders** in the application or visit your **Prestigio Cabinet** on the web-pages to check the order and download a book separately.



Prestigio Cabinet can be found on the main screen of OPDS catalog in the bottom line.



My account shows up only to sign in users.

My Prestigio will help you to control your balance, personal info and orders without going into Prestigio web site.

Overview. General information about account holder and his/her balance.

Personal Info. Login, first/last name, country of residence and phone number. Also option to Change password.

Language. Language of the books preferred for reading.

My Balance. Quick option to refill balance and continue buying books with one touch only.

My orders. List of all transactions made by a user in application or at Prestigio site www.ebooks.prestigioplaza.com.



Once download links are not expired it's possible to get a book from an order details to a mobile device. Downloaded book will be available in "My books" after Refreshing collections or can be found in section **My Library** using File tree.